



PDM TO CDM POWER CONNECTIONS

DSX-1040PDM TO 1040CDM CONNECTIONS

This diagram shows the power connections between the DSX-1040PDM and the DSX-1040CDM modules.

Note:

- 4 - 18awg wires leaving terminals 4,5,6,7 on the PDM
- All Four - 18awg wires connect to terminal 13 (+) and 15 (-) on the CDM .
- Not making these connections properly could leave the system underpowered.

